

### **Bluetooth Adapter**

**Operation Manual** 

### Specifications

- 1.Bluetooth version: V2.0+EDR, Class 2
- 2.Bluetooth profiles: A2DP & AVRCP
- 3.Bluetooth frequency range: 2.4GHz-
- 2.4835GHz
- 4.Effective range: over 30 feet

#### Introduction

- 1.Bluetooth music receiver is specifically designed for use with 30 pin iPod® docking station.
- 2.Plug this receiver into your iPod® docking station, the music will be transmitted to dock station from your Bluetooth enabled device.
- 3.Simple plug & play and requires no additional power.

## Connecting Music Receiver to the dock station

1.Turn on the dock station before plugging the receiver.

2.Then set the audio source to iPod®.

3.Finally plug the receiver into the iPod® dock 30 pin connector port and the receiver will start to flash blue and red alternately.

# Pairing Music Receiver with a Bluetooth device

- 1.Once the receiver is plugged in, it will automatically enter into pairing mode.
- 2.At this time you can turn on your Bluetooth device to search for "Music Receiver" and pair it.
- 3.When "Music Receiver" is detected, enter the PIN "0000" and confirm.
- 4.After successful pairing, select "Music Receiver" from Bluetooth device list and press "connect".
- 5.After successful connecting, the indicator light of Music Receiver will be blue flashing slowly.

#### **FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

AXCEL ELECTRONICS AMERICA LLC 13506 Summerport Village Parkway Suite 267 Windermere, FL 34786 888-408-1088 WWW.AXCEL-ELECTRONICS.COM